

### HyDraw<sup>®</sup> "Power-to-Design" circuits

| Restructured Ribbon Menu              |
|---------------------------------------|
| Custom External Ports                 |
| Design Notes: Show/Hide and Note List |
| Pump-Motor Adaptor Selection          |
| Gauge Port: Configure and Insert      |
| Select from Linked Accessories        |
| Hoses: Hose ID and Hose List          |
| Component as Accessory                |

| ERP Interface                |  |  |  |
|------------------------------|--|--|--|
| Net Pressure                 |  |  |  |
| Restructured HyDraw Options  |  |  |  |
| New Hose ID Numbering Scheme |  |  |  |
| Search by Part Number        |  |  |  |
| Migrate Settings             |  |  |  |
| Import & Export Settings     |  |  |  |


#### **HyDraw** Library Manager 2015

ERP Interface Manager


Component as Accessory



#### Restructured Ribbon Menu










Menu restructured: Circuit, System and Services tabs


#### **Custom External Ports**




#### Design Notes: Show/Hide and Note List











Create a Design Note list


#### **Pump Motor Adaptor Selection**




Select Pump/Motor Adaptor based on Pump and Motor properties



#### Configure and Insert Gauge Port




#### Select from Linked Accessories



Select data from Linked Accessories when inserting symbol from HyDraw Library Explorer or Select data from library in the HyDraw Property Manager




#### Hoses: Hose ID and Hose List



| Layout | Parametric | View                 | Manage | Output       | Help      | ₽ .               |                             |    |
|--------|------------|----------------------|--------|--------------|-----------|-------------------|-----------------------------|----|
| Parts  | Ports Hose | Act                  | Crea   | ite a H      |           | ist for s<br>wing | selecte<br>Unit<br>onverter | ed |
|        |            | Create H<br>Create a |        | nd display i | n drawing | g or export to    | Excel.                      |    |

| HOSE ID | QTY | DESCRIPTION                  |
|---------|-----|------------------------------|
| H1      | 2   | HOSE- SAE100 R12 3/4 X 36    |
| H2      | 1   | HOSE SAE 100 R 12 1 1/4 X 72 |
| H3      | 1   | HOSE SAE100 R12 3/4 X 48     |

#### Use Component as Accessory





Add a Component as an Accessory in the HyDraw Property Manager

#### **ERP Integration**


ERP integrated with the HyDraw Ribbon Menu and its settings in HyDraw Options








#### **Restructured HyDraw Options**




#### New Hose ID Numbering Scheme




**Hose ID** Numbering Scheme

#### Search by Part Number


Search for a Symbol/Model by **Part Number** 









#### Migrate Settings



#### Import & Export HyDraw Settings









## Library Manager 2015

HyDraw® CAD800 What's New







#### **ERP Interface Manager**




Create the ERP Configuration XML file - Import data from ERP Excel spreadsheet







#### **Use Component as Accessory**



Add a Component as an Accessory in the HyDraw Library Manager

# FREE '

HyDraw<sup>®</sup> CAD<sup>800</sup> Evaluation Software

Call: +1 (248) 649 9550

Email: sales@VESTusa.com

Visit: <u>www.VESTusa.com</u>

